

Sunbeam

Feel Perfect

Heated Throw with SleepPerfect® Technology

Instruction Booklet

Please read these instructions carefully
and retain for future reference.



Contents

Sunbeam's Safety Precautions	1
Safety Precautions for your heated throw	2
Sunbeam's SleepPerfect® Technology	3
Features of your Feel Perfect Heated Throw	4
Using your heated throw	5
Troubleshooting	6
Care and cleaning	7

تأكد من تفهم احتياطات السلامة المذكورة اعلاه

請務必理解上述的安全預防措施。

Assurez-vous que les précautions ci-dessus relatives à la sécurité sont bien comprises

Versichern Sie sich daß die obenstehenden Sicherheitsmaßnahmen Verstanden werden

Βεβαιώστε πως οι παραπάνω προφυλάξεις ασφαλείας γίνονται κατανοητές

Pastikan bahwa tindakan-tindakan keselamatan seperti di atas dimengerti anda

Accertatevi che le suddette norme di sicurezza siano comprese a dovere

上記の注意事項をよくお読みになり、安全を御確認ください

Уверете се дека погоре споменатите мерки на претпазливост се добро разбрани

Asegúrese de que las precauciones de seguridad precedentes sean bien comprendidas

کاری بکنید کہ احتیاط‌های بالا حتماً درک بشوند

ต้องแน่ใจว่า ข้อควรระวังเรื่องความปลอดภัยข้างต้น เป็นที่เข้าใจกันดี

Yukarda belirtilen güvenlik önlemlerinin anlaşıldığından emin olunuz

Xin kiểm chắc rằng những biện pháp làm an toàn kể trên được hiểu rõ

Sunbeam's Safety Precautions

Sunbeam is very safety conscious when designing and manufacturing consumer products, but it is essential that the product user also exercise care when using an electrical appliance. Listed below are precautions which are essential for the safe use of an electrical appliance:

- Read carefully and save all the instructions provided with an appliance.
- Always turn the power off at the power outlet before you insert or remove a plug. Remove by grasping the plug - do not pull on the cord.
- Turn the power off and remove the plug when the appliance is not in use and before cleaning.
- Do not use your appliance with an extension cord unless this cord has been checked and tested by a qualified technician or service person.
- Always use your appliance from a power outlet of the voltage (A.C. only) marked on the appliance.
- Close supervision is necessary when your appliance is being used by children or infirm persons.
- Young children should be supervised to ensure that they do not play with the appliance.
- Never leave an appliance unattended while in use.
- Do not use an appliance for any purpose other than its intended use.
- Do not place an appliance on or near a hot gas flame, electric element or on a heated oven. Do not place on top of any other appliance.
- Do not let the power cord of an appliance hang over the edge of a table or bench top or touch any hot surface.
- Do not operate any electrical appliance with a damaged cord or after the appliance has been damaged in any manner. If damage is suspected, return the appliance to the nearest Sunbeam Appointed Service Centre for examination, repair or adjustment.
- For additional protection, Sunbeam recommend the use of a residual current device (RCD) with a tripping current not exceeding 30mA in the electrical circuit supplying power to your appliances.
- Do not immerse the appliance in water or any other liquid unless recommended.
- Appliances are not intended to be operated by means of an external timer or separate remote control system.

If you have any concerns regarding the performance and use of your appliance, please visit www.sunbeam.com.au or contact the Sunbeam Consumer Service Line. Ensure the above safety precautions are understood.

Safety Precautions for your Electric Throw Rug

- Do not switch the blanket on if moist or wet.
- Do not use pins, needles, safety pins or other sharp items on your electric throw.
- Do not dry clean your electric throw.
- Examine periodically for signs of wear or damage on the blanket cords. If there are such signs, or the blanket has been misused, return it to an authorised service agent for inspection.
- Only use your electric throw with the controls supplied or marked equivalent.
- Do not use with infants, infirm persons, or persons insensitive to heat.
- Parents or guardians must preset the controls for young children, unless the child has been adequately instructed on how to operate the control safety.
- Ensure that the electric throw is switched off and unplugged after use.
- This electric throw is not intended for use in hospitals.
- If appliance is used on an adjustable bed, check that the blanket and cord do not become trapped or rucked, for example in hinges.
- When storing the appliance allow it to cool down before folding.
- Do not crease the appliance by placing items on top of it during storage.
- Should your appliance suffer a thermal or fuse link rupture (normally identified when the blanket stops heating) please return it to the manufacturer or agent for repair or replacement.

Important instructions – retain for future use.

If you have any concerns regarding the performance and use of your appliance, please visit www.sunbeam.com.au or contact the Sunbeam Consumer Service Line. Ensure the above safety precautions are understood.

Care Label Symbols



Attention



Instruction Booklet - Please read the instructions thoroughly before use

Sunbeam's SleepPerfect® Technology

Temperature sensitive, fast-heating elements

All Sunbeam Feel Perfect electric blankets feature our exclusive SleepPerfect® technology. This technology uses a unique heating element that adjusts the heat level of your electric blanket to maintain your selected setting.

A built-in microprocessor continually senses changes in room and body temperature and adjusts the power input accordingly, to provide a constant level of comfort.

The unique flexible heating element allows the fabric to drape around you, enabling the heated throw to be used on the lounge or your favourite arm chair.

This unique element also heats up to reach your selected temperature in just 10 minutes, so there's no need for hours of preheating.

Nine levels of safety protection

Nine levels of total safety protection make Sunbeam's Feel Perfect range safer than any other electric blanket. A built-in microprocessor constantly senses the resistance of the heating wire and adjusts the power input accordingly. It senses any rise in temperature and reduces the power supply to prevent overheating.

In the unlikely event of a fault, the microprocessor senses the abnormal operation and automatically cuts off power to the blanket.

A second microprocessor acts as a back up should the first fail.

For additional safety protection, all Feel Perfect electric blankets contain a thermal back up fuse that is independent of the blanket control. It detects any abnormal temperature variations in the heating element and automatically switches the blanket off to prevent overheating.

Features of your Feel Perfect Heated Throw

TR6100 Faux Fur Heated Throw

Your Feel Perfect heated throw has the following features:

SleepPerfect® Technology

Sunbeam's exclusive SleepPerfect® technology continually senses and adjusts to changes in your room and body temperature to maintain your selected heat setting. So when the temperature drops outside, you'll stay safe and warm.

Luxurious Faux Fur

The ultimate in luxury! The 550g/m² top layer of faux fur with an underside of micro fleece will keep you warm this Winter.

Machine washable

The detachable control and waterproof heating element make your electric throw safe to machine wash and may be tumble dried.

For instructions on how to launder your Feel Perfect Heated Throw IB Heated Throw, see the Care and cleaning section on page 7.

9 heat control

A choice of nine heat settings allows you to select the desired temperature to keep you comfortable, day or night. The setting dial illuminates to enable easy adjustment in the dark.

Detachable control

Remove the control when laundering your blanket, or when storing.

Using your heated throw

Using your heated throw

Your heated throw can be used on the lounge or in your favourite chair, providing cosy comfort wherever you need it. It can even be used on futons, adjustable beds and waterbeds.

Connecting the control

With the control set to the off position, insert the control connector into the socket, making sure it is firmly clicked into position. Plug the control into a 230-240V power outlet and turn the power on.

Note: ensure that the control is connected to the heated throw before inserting the plug into the power outlet. Connecting the power before attaching the control to the blanket will replicate a power interruption and activate the safety system, preventing the throw from heating.


Caution: keep the control away from heating sources such as heaters and lamps. Do not cover the control.

Using your heated throw

Your heated throw is supplied with a 9 heat control. The settings on the temperature dial are recommended for use as follows:

- 1 – 3 Low, gentle heat for all night use
- 4 – 6 Medium heat
- 7 – 9 High heat, for preheating only

Use the high heat settings to preheat the throw only. Do not use your heated throw on these settings for more than 30 minutes.



Troubleshooting

Should your heated throw fail to heat, check the following:

1. Check that the control is properly connected to the heated throw and clicked securely into position. If you find the control connector plug is not properly fitted to the heated throw, switch the power off at the power outlet, securely attach the control connector plug to the heated throw, and then switch the power back on.
2. Check that the power cord is connected to the power outlet and the power is switched on.

Care and cleaning

All Feel Perfect electric blankets feature waterproof heating elements, making them fully immersible and safe to wash by hand or machine.

Before cleaning your throw rug, ensure that the controls are unplugged from the throw rug.

Spot cleaning

Sponge the affected area using a neutral wool detergent or mild soap flakes mixed with lukewarm water. Sponge twice with clean water to remove detergent. Remove excess water by compressing the wet area between two towels.

Hand washing

Wash the throw rug in lukewarm water with a neutral wool detergent or mild soap flakes. Soak for five minutes, then gently squeeze the soapy water through the fabric. Rinse thoroughly in clean, lukewarm water then drain excess water from the throw rug. Do not wring.

Machine washing

Take your throw rug to a commercial laundry or wash in a domestic washing machine (size permitting). Wash on WOOL or DELICATES cycle with a neutral wool detergent or mild soap flakes, below 40°C. Do not use high speed or extra spin cycles.

Line drying

Drape the throw rug across several lines of your clothesline. Do not use pegs on the wired areas. Do not dry with a hairdryer or heater. Ensure that the throw rug and control sockets are completely dry before using again.

Machine drying

Tumble dry your throw rug on LOW setting for 15 minutes MAXIMUM. Smooth the throw rug by gently pulling any creases out of the fabric. Line dry to ensure the throw rug and control sockets are completely dry before use. Do not dry with a hairdryer or heater.

Storing your blanket

Roll or fold your heated throw loosely and store in a blanket bag or the bag it was supplied in. Avoid pressing sharp creases into the heated throw.

Do not place heavy items on top of your heated throw when storing.

Notes

3 Year Replacement Guarantee

In the unlikely event that this appliance develops any malfunction within 3 years of purchase (3 months commercial use) due to faulty materials or manufacture, we will replace it for you free of charge.

Should you experience any difficulties with your appliance, please phone our customer service line for advice on 1300 881 861 in Australia, or 0800 786 232 in New Zealand. Alternatively, you can send a written claim to Sunbeam at the address listed below. On receipt of your claim, Sunbeam will seek to resolve your difficulties or, if the appliance is defective, advise you on how to obtain a replacement or refund.

Your Sunbeam 3 Year Replacement Guarantee naturally does not cover misuse or negligent handling and normal wear and tear.

Similarly your 3 Year Replacement Guarantee does not cover freight or any other costs incurred in making a claim. Please retain your receipt as proof of purchase.

The benefits given to you by this guarantee are in addition to your other rights and remedies under any laws which relate to the appliance.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law and under the New Zealand Consumer Guarantees Act.

In Australia you are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Should your appliance require repair or service after the guarantee period, contact your nearest Sunbeam service centre.

For a complete list of Sunbeam's authorised service centres visit our website or call:

Australia

www.sunbeam.com.au

1300 881 861

Units 5 & 6, 13 Lord Street
Botany NSW 2019 Australia

New Zealand

www.sunbeam.co.nz

0800 786 232

26 Vestey Drive, Mt Wellington
Auckland, New Zealand

Need help with your appliance?

Contact our customer service team or visit our website for information and tips on getting the most from your appliance.

In Australia

Visit www.sunbeam.com.au

Or call 1300 881 861

In New Zealand

Visit www.sunbeam.co.nz

Or call 0800 786 232

 is a registered trademark.

'Feel Perfect' and 'SleepPerfect' are registered trademarks of Sunbeam Corporation.

Made in China.

Due to minor changes in design or otherwise, the product may differ from the one shown in this leaflet.

© Copyright. Sunbeam Corporation Limited 2005-2012.

ABN 45 000 006 771

Sunbeam Corporation is a division of GUD Holdings Ltd.